



Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Varaosat / Varasat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Pieśe de schimb /
 Rendelhető alkatrészek / Запасні частини / Reservní delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daju

Position

- 1 = A 962040 AA
- 2 = A 962041 NU
- 4 = A 962042 AA
- 5 = A 961667 NU (2x)
- 7 = A 960 567NU
- 8 = A 961335 NU
- 9 = A 963154 NU





- 11 = A 963309 NU
- 13 = A 962043 NU
- 15 = A 960001 NU
- 16 = A 962044 AA
- 18 = A 962045 NU
- 19 = A 962370 NU
- 20 = A 963404 NU
- 21 = A 961230 AA
- 23 = A 960019 AA
- 24 = B 964902 AA
- 25 = A 960196 NU



MELANGE


A 4258 .. A 4260 .. A4268 .. A4287 ..
 A 5962 ..





0116 / A 865 736
 (+ A 865 612)



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar		0,5			Q (3 bar)
	T	°C					l/min 13