





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

Position


- 1 = A 960 645 AA
- 3 = B 960 473 AA
- 5 = A 960 646 AA
- 9 = A 962 716 NU
- 17 = A 960 647 NU
- 21 = A 960 650 NU
- 23 = A 960 651 AA
- 28 = A 960 654 AA
- 32 = A 961 230 AA




ATTITUDE

A 4596 .. A 4598 .. A 4599 ..


0116 / A 866 053
 (+ A 865 612)
 Made in Germany




A4599



A 4596


















A 4598



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





| | | | | | | |
|--|--------------|-----|---------|----|--|------------------|
| | P bar | 0,5 | MAX. 10 | 5 | | Q (3 bar) |
| | T °C | | MAX. 80 | 65 | | l/min |
| | | | | 40 | | 5 |