





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, GN, ...

Pos.	Part No.
1	A 861 452 XX
2	A 860 603 NU
3	A 861 453 NU
4	A 861 080 XX
5	B 961 087 NU
7	B 961 086 NU
8	F 960 855 NU
9	H 962 197 NU
10	A 861 234 XX
11	A 861 454 XX
16	A 861 270 NU
18	A 963 495 NU
20	A 961 863 NU
21	A 962 625 NU
23	A 861 069 NU
26	F 960 881 NU
27	A 963 548 NU
31	A 860 845 NU
34	F 960 867 NU




Ideal Standard


CONNECT AIR

1119 / A 868 364

A 7009 .. A 7029 ..



A 7009 ..



A 7029 ..



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com



