







Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb  
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /  
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA, A5, ...

Pos.	Part No.		
1	A 963 131 NU	11	A 860 902 XX
2	A 963 132 NU	12	A 860 897 NU
3	A 963 146 NU	13	A 861 445 XX
4	A 960 890 NU	14	A 860 901 XX
5	A 960 891 NU	15	A 861 448 XX
6	A 960 706 NU	16	A 960 704 NU
7	A 962 866 NU		A 962 476 NU
8	A 963 443 NU	17	A 861 444 XX
9	A 960 500 NU		
10	A 861 441 XX		




Ideal Standard

JOY NEO


A 7623 ..




0322 / A 869 024








Ideal Standard International NV  
 Corporate Village - Gent Building  
 Da Vincilaan 2  
 1935 Zaventem  
 Belgium

www.idealstandardinternational.com





Pressure 0,3 MPa 3 bar	Temperature °C	Symbol	0	1	2	3	4	5	6	7	8	9
			°C	°C	°C	°C	°C	°C	°C	°C	°C	°C
50°C	16°C	❄️	49,5	49,5	48	46	42,5	41	37	33,5	31	28
65°C	16°C		65	65	63,5	60,5	57	53,5	49	44,5	39	34,5
81°C	16°C		81	81	78,5	73	69	63,5	56	49	42,5	36



	<b>P</b>	bar	0,5	MAX. 10	5		<b>Q</b> (3 bar)
	<b>T</b>	°C		MAX. 80	65		<b>l/min</b>
					40		<b>23</b>