





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA, AD...


Pos.	Part No.
1	A 962 397 XX
2	A 963 667 NU
3	A 960 893 XX*
5	A 963 783 NU
6	A 960 500 NU
7	F 960 966 XX
8	A 962 274 XX
9	B 960 497 NU
10	A 962 270 NU
11	F 960 967 XX
12	A 963 495 NU
16	A 963 526 NU
18	A 963 524 NU
21	F 960 881 NU
22	A 963 548 NU
26	A 860 845 NU
29	F 960 866 NU



MARA
A 9042 ..







0715 / A 866 677
 (+ A 865 612)
 Made in Germany



Ideal Standard International BVBA
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar		MAX. 10		5		Q (3 bar)
	T	°C		MAX. 80		65		
						55		l/min 14

