





Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Teltitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD, .....




- |                  |                    |
|------------------|--------------------|
| 1 - B 961768 XX  | 10 - B 960900 XX   |
| 2 - A 963751 NU  | 11 - A 962370 NU   |
| 3 - A 861420 XX  | A 962005 NU        |
| 4 - A 861397 NU  | (BD155..; BD156..) |
| 5 - A 861417 XX  | 12 - A 964520 NU   |
| 6 - B 961120 NU  | 13 - A 960200 XX   |
| 7 - B 961767 XX  | 14 - B 960255 NU   |
| 7a - B 961765 XX | 15 - A 961230 XX   |
| 8 - A 962708 NU  |                    |
| 9 - B 960583 NU  |                    |



B D155 ..




B D156 ..




Ideal Standard

JOY NEO


01.2022 / B565158




B D147 ..



B D149 ..







B D148 ..














B D150 ..



Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium  
<http://www.idealstandardinternational.com>



B D155 ..  
B D156 ..



P	°C	°C	°C	°C	°C	°C
50°C	15°C	27	33	41	48	50
65°C	15°C	33	42	53	63	65
85°C	15°C	41	53	68	83	85

P	bar	0,5	MAX. 10	5	Q (3 bar)
T	°C	MAX. 80	65	40	l/min
					5