






Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservdelar / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Зпасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA,AD,..


- 1 F 960 851 AA
- 2 A 860 603 NU
- 3 F 960 854 AA
- 6 F 960 855 NU
- 8 F 960 858 AA
- 9 F 960 859 AA
- 12 A 962 294 NU
- 14 A 962 625 NU
- 16 A 961 863 NU
- 17 A 963 495 NU
- 20 H 961 506 NU
- 24 F 960 881 NU
- 25 A 963 548 NU
- 29 A 860 845 NU



JADO

JES
H 4492 ..




0915 / A 866 568
 (+ A 865 613)
 Made in Germany



Ideal Standard International BVBA
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P bar		MAX. 10		5		Q (3 bar)	
	T °C		MAX. 80		65		l/min	
					55		5	

