






Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Зпасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA,AD,..


- 1 F 960 852 AA
- 2 A 963 309 NU
- 3 B 960 473 AA
- 4 B 960 276 AA
- 6 A 963 176 NU
- 7 A 960 500 NU
- 9 H 960 294 NU
- 10 F 960 896 AA
- 11 A 963 413 NU
- 12 A 962 625 NU
- 15 A 963 026 NU
- 17 A 963 805 NU
- 20 A 962 823 NU
- 21 A 963 287 AA
- 22 H 960 185 NU
- 23 H 961 444 AA
- 24 H 960 279 NU
- 29 F 960 865 AA
- 30 B 961 093 NU
- 31 F 960 900 AA



JADO

JES
H 4498 ..



0914 / A 866 572
 (+ A 865 613)
 Made in Germany



Ideal Standard International BVBA
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar		MAX. 10		5		Q	(3 bar)
	T	°C		MAX. 80		65			l/min
						55			8

