




Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, AD...

Position

- 1 A 963 470 NU
- 2 A 963 471 NU
- 3 A 963 472 NU
- 4 A 963 469 NU
- 5 A 962 574 NU
- 10 F 960 863 AA
- 11 H 860 835 NU
- 13 H 960 873 NU
- 15 F 960 864 AA
- 18 A 860 464 NU
- 19 H 3990 NU
- 20 A 963 477 NU





JADO

JES


H 4508 ..


0316 / A 866 580
 (+ A 865 613)
 Made in Germany



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com








max / min

1



2



<p>P</p>	<p>bar</p>	<p>0,5</p>	<p>5</p>
<p>T</p>	<p>°C</p>	<p>MAX. 80</p>	<p>65</p> <p>55</p>