




CERABASE

Ideal Standard



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961852AA	1 Set				
2	Rubber button	A963751NU	1 Pcs.				
3	Cap M38x1.5	B961373AA	1 Pcs.				
4	Screw M38x1.5	B961374NU	1 Set				
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	A861156NU*	1 Set				
7	Aerator M24x1-5 l/min	B960754AA	1 Pcs.				
7a	Aerator M24x1-1G/min	B960883AA**	1 Pcs.				
8	Fixation set	A964520NU	1 Set				
9	Pull-up rod-compl.	B960900AA	1 Set				
10	Pop-up waste-plastic	B964550AA	1 Pcs.				
10a	Pop-up drain ass.	A962991AA	1 Pcs.				
10b	Click waste plastic	B961705AA	1 Pcs.				

*Universal set (not all parts needed)

** for BC833AA