




CERABASE

Ideal Standard



BC837AA

Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever	B961854AA	1 Set				
2	Rubber button	A963751NU	1 Pcs.				
3	Rosette M41x1.5	B961386AA	1 Pcs.				
4	Screw M41x1.5/M46x1.5	B961387NU	1 Set				
5	Hot limit stop	A861181NU	1 Pcs.				
6	Cartridge Ø38mm	A861156NU*	1 Set				
7	Fixation set	A964520NU	1 Set				
8	Tub.spout R120-5 l/min	B961840AA	1 Set				
9	Perlator M22x1-A-5 l/min	B961841AA	1 Pcs.				
10	O-Ring Ø13x2.5	A962728NU	2 Pcs.				
11	Click waste plastic	B961705AA	1 Pcs.				

*Universal set (not all parts needed)