GUSTO

Ideal Standard

BD412AA



ND = Version for low pressure

Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever,w/logo	B961808XX	1 Set				
2	Rubber button	A963751NU	1 Pcs.				
3	Cover cap	A861420AA	1 Set				
4	Cartridge Ø28mm	A861397NU	1 Set				
5	Tub.spout R204mm,ND	B961810AA	1 Set				
6	Flow straight, ND	B960500AA	1 Pcs.				
6a	Key for stream regulator	A960196NU*	1 Set				
7	Sealing set	B960839NU*	1 Set				
8	Rubber cap Ø8.1x3	B960583NU	1 Set				
9	Rosette decorative	B961806AA	1 Set				
10	Fixation set	B961807NU	1 Set				
11	Fl.hose G3/8/M8x1 /L500	A962005NU	1 Pcs.				
11a	Flex hose G3/8 /L445	A963600NU	1 Pcs.				
12	Flow limiter-6 l/min	A860984NU	1 Pcs.				

**Universal set (not all parts needed)*